


3110 Series $\frac{3}{4}$ " - 2" Brass Electric Valves



H
A
Y
S




Item #	Description	$\frac{3}{4}$ "	1"	1 $\frac{1}{4}$ "	1 $\frac{1}{2}$ "	2"
	Cover Assembly	11125	11133	11136	11137	11138
1	Cover Only	OBSOLETE	689403	OBSOLETE	688203	714601
2	Bleed Screw	DC10	DC10	DC10	DC10	DC10
3	Cover Bolt*	5502	5502	5502	5502	5459
4	Diaphragm Assembly	10984	11378	11312	11311	11310
5	Strainer Basket	6565	6565	6565	6565	6565
6	Positioning Eyelet	6364	6364	6364	6364	6364
7	Diaphragm Spring	2486	2488	2488	2488	4554
8	24 Volt Solenoid Assy.	6969-24	6969-24	6969-24	6969-24	6969-24
8	110 Volt Solenoid Assy.	6969-110	6969-110	6969-110	6969-110	6969-110
9	Plunger Assembly	41973	41973	41973	41973	41973
10	Plunger Spring	4198	4198	4198	4198	4198
11	Plunger Housing	41922	41922	41922	41922	41922
12	Plunger Housing Nut	4194	4194	4194	4194	4194
13	Plunger Housing Gasket	RCO110004	RCO110004	RCO110004	RCO110004	RCO110004
14	24 VAC Coil	5734	5734	5734	5734	5734
15	110 VAC Coil	5709	5709	5709	5709	5709
16	Coil Retainer	2958	2958	2958	2958	2958
17	Solenoid Removal Tool	4539	4539	4539	4539	4539

*Not included in Cover Assy.



H
A
Y
S

3112 Series 3/4" - 3" Brass Electric Valves



Item #	Description	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
	Cover Assembly	11125	11133	11136	11137	11138	11115	11114
1	Cover Only	689903	689503	688703	688303	714601	7147	7148
2	Bleed Screw	DC10	DC10	DC10	DC10	DC10	DC10	DC10
3	Flow Control Stem	62741	62741	62741	62741	62741	62741	62741
4	Flow Stem O-Ring	RCO110011	RCO110011	RCO110011	RCO110011	RCO110011	RCO110011	RCO110011
5	Cover Bolt**	5502	5502	5502	5502	5459	5459	5459
6	Diaphragm Assembly	10984	11378	11312	11311	11310	11318	11317
7	Strainer Basket	6565	6565	6565	6565	6565	6565	6565
8	Positioning Eyelet	6364	6364	6364	6364	6364	6364	6364
9	Diaphragm Spring**	2486	2488	2488	2488	4554	4554	4554
10	24 Volt Solenoid Assy.	6969-24	6969-24	6969-24	6969-24	6969-24	6969-24	6969-24
10	110 Volt Solenoid Assy.	6969-110	6969-110	6969-110	6969-110	6969-110	6969-110	6969-110
11	Plunger Assembly	41973	41973	41973	41973	41973	41973	41973
12	Plunger Spring	4198	4198	4198	4198	4198	4198	4198
13	Plunger Housing	41922	41922	41922	41922	41922	41922	41922
14	Plunger Housing Nut	4194	4194	4194	4194	4194	4194	4194
15	Plunger Housing Gasket	RCO110004	RCO110004	RCO110004	RCO110004	RCO110004	RCO110004	RCO110004
	24 VAC Coil	5734	5734	5734	5734	5734	5734	5734
	110 VAC Coil	5709	5709	5709	5709	5709	5709	5709
16	Coil Retainer	2958	2958	2958	2958	2958	2958	2958
	Solenoid Removal Tool	4539	4539	4539	4539	4539	4539	4539

* Not included in Cover Assembly.

** Not included in Assembly.